

GB Instruction for use
LV Lietošanas pamācība

POWERTEX

Beam Clamp PBC-S1



User Manual

POWERTEX Beam Clamp PBC-S1 1 – 10 ton

Assembly / Instruction for use (GB) (Original instructions)


Read through these user instructions carefully before using the beam clamp. Improper operation may lead to hazardous situations!

The POWERTEX beam clamp is designed for mounting on the lower flange of an I-beam for suspending a load or lifting device. The beam clamp is fixed in position with a right-hand and left-hand threaded rod in a scissor construction.

Safety rules

- The beam on which the clamp is to be mounted must be checked by a competent person. This person must assess the beam's load bearing capacity and fixings and its suitability for the purpose.
- Check the beam clamp before use for function and any cracking, deformation or wear.
- Load on the beam clamp must not exceed the maximum load indicated on the rating plate.
- The beam clamp must only be used for beams with a flange width within the range indicated on the rating plate.
- The clamp must be fixed to the beam above the load's centre of gravity.
- Dynamic stresses must be avoided.
- Inclined pulls are not permitted.
- Working temperature: -10°C to +50°C.

Dimensioned sketch



Technical data

Model	WLL (ton)	I beam width range (mm)	A max.	B min.	B max.	C	D (mm)	E	F min.	F max.	G min.	H	Weight (kg)
PBC-S1	1	80-240	270	183	370	94	4	198	100	154	22	20	3,5
PBC-S1	2	80-240	270	183	370	102	6	198	100	154	22	20	4,5
PBC-S1	3	90-330	355	243	500	132	8	263	148	219	46	22	9,5
PBC-S1	5	90-330	355	243	500	142	10	263	148	219	43	28	11
PBC-S1	10	90-350	364	269	521	180	12	285	165	239	51	38	16

Safety factor: 4:1

Static test coefficient: WLL x 2

Generally according to EN 13155

Mounting

Open the beam clamp by unscrewing the threaded rod with the handle sufficiently to allow the clamp to enclose the beam. Screw up the beam clamp centrally over the load's centre of gravity. Make sure the arms on the beam clamp have a secure grip on the beam flange. (See dimensioned drawing).

The load or suspension hook on the lifting device must hang centrally from the bowed centre of the suspension bolt.

Continuous maintenance - lubrication

Bearings and threaded sections and the surface of the suspension bolt in contact with the load hook must be cleaned and lubricated as necessary. Periodic checks must normally be carried out yearly to detect and remedy any faults. Damaged parts must be replaced with original POWERTEX parts. A set of threaded rods and nuts can be ordered through your dealer.

Contact your dealer for spare parts in general.

Replacing the threaded rod.

- Open the beam clamp as far as it will go.
- Knock the locking pin out of the handle.
- Completely unscrew the threaded rod.
- Remove the old nuts by pressing them out of the beam clamp's arms. Dismantle and clean the spacers.
- Mount the new nuts together with the spacers.
- Oil and screw the new threaded rod into the nuts. Make sure both threads go in simultaneously.
- Screw up until the handle can be mounted and lock with the locking pin.
- Continue screwing to the desired position.

Instruction Grey Label

To change your new POWERTEX Beam Clamp to Blackline:
If the product should be used in dark environments, add the grey label on the product's name plate like this.
The data on the nameplate should ALWAYS be visible, and must NOT be covered.

If the product is modified in any way, or if it is combined with a non-compatible product / component, SCM Citra OY takes no responsibility for the consequences in regard to the safety of the product.

EC Declaration of conformity

SCM Citra OY
Asessorinkatu 3-7
20780 Kaarina, Finland
www.powertex-products.com
hereby declares that the POWERTEX product as described above is in compliance with EC Machinery Directive 2006/42/EC & EN 13155.

UK Declaration of conformity

SCM Citra OY
Asessorinkatu 3-7
20780 Kaarina, Finland
www.powertex-products.com
hereby declares that the POWERTEX product as described above is in compliance with the Supply of Machinery (Safety) Regulations 2008 & BS EN 13155.

POWERTEX sijas skava PBC-S1 1 – 10 ton

Uzstādīšana / Lietošanas pamācība (LV)


Pirms sijas skavas izmantošanas izlasiet šo lietošanas pamācību.
Nepareiza lietošana var būt bīstama!

POWERTEX sijas skava ir paredzēta stiprināšanai uz dubultas T profila sijas apakšējā atloka, lai piekarinātu kravu vai pacelšanas ierīci. Sijas skavu nostiprina ar šķērveida konstrukcijas labās un kreisās puses vītnstieni.

Drošības noteikumi

- Sija, uz kuras paredzēts uzstādīt skavu, ir jāpārbauda speciālistam. Šai personai ir jānovērtē sijas un tās stiprinājumu izturība un piemērotība paredzētajam mērķim.
- Pirms lietošanas pārbaudiet, vai sijas skava darbojas un nav ieplaisājusi, deformēta vai nodilusi.
- Sijas skavas noslodze nedrīkst pārsniegt uz markējuma norādīto maksimāli pieļaujamo slodzi.
- Sijas skavu drīkst uzstādīt tikai uz tādām sijām, kuru atloka platums atbilst uz markējuma norādītajam.
- Skava jānostiprina sijas vidū virs kravas smaguma centra.
- Jāizvairās no dinamiskās slodzes.
- Nedrīkst vilkt kravu sliipā plaknē
- Darba temperatūra: -10°C līdz +50°C.

Rasējums ar izmēriem



Tehniskie parametri

Modelis	WLL (tonnās)	Atvērums (mm)	A max.	B min.	B max.	C	D	E	F min.	F max.	G min.	H	Svars (kg)
(mm)													
PBC-S1	1	80-240	270	183	370	94	4	198	100	154	22	20	3,5
PBC-S1	2	80-240	270	183	370	102	6	198	100	154	22	20	4,5
PBC-S1	3	90-330	355	243	500	132	8	263	148	219	46	22	9,5
PBC-S1	5	90-330	355	243	500	142	10	263	148	219	43	28	11
PBC-S1	10	90-350	364	269	521	180	12	285	165	239	51	38	16

Drošības koeficients: 4:1.

Pārbaudes slodze: WLL x 2.

Standarts: EN 13155.

Uzstādīšana

Atveriet sijas skavu, aiz roktura atskrūvējot vītnstieni tik tālu, lai skava varētu aptvert siju. Uzskrūvējiet sijas skavu pa vidu virs kravas smaguma centra. Pārliecinieties, ka sijas skavas satvērējķepas ir stingri piestiprinātas pie sijas atloka. (Skatiet rasējumu ar izmēriem).

Kravai vai pacelšanas ierīces piekares āķim ir jākarājas pa vidu no piekares skrūves izliektā vidūs.

Regulāra apkope – eljošana

Gultī, vītnes un piekares skrūves virsma, kas saskaras ar kravas āķi, ir jātīra un jāeeļlo pēc vajadzības. Lai konstatētu un novērstu defektus, reizi gadā jāveic periodiskas apkopes. Bojātās detaļas ir jānomaina ar oriģinālām POWERTEX detaļām. Vītnstieņu un uzgriežņu komplektu varat pasūtīt pie savā piegādātāja.

Sazinieties ar izplatītāju par rezerves daļām kopumā.

Vītnstieņa maiņa.

- Atveriet sijas skavu, cik plati vien iespējams.
- Izsitiet no roktura fiksēšanas tapu.

3 Pilnībā izskrūvējiet vītnstieni.

4 Izņemiet vecos uzgriežņus, izspiežot tos no sijas skavas satvērējķepām. Izņemiet un nošķirt starplikas.

5 Uzlieciet jaunos uzgriežņus un starplikas.

6 Ieeļojiet jauno vītnstieni un ieskrūvējiet to uzgriežņos. Abām vītnēm ir jāieskrūvējas vienlaikus.

7 Skrūvējiet, kamēr var uzstādīt rokturi, un nostipriniet to ar fiksēšanas tapu.

8 Turpiniet skrūvēt līdz vēlamajam stāvoklim.

Instrukcija par pelēko etiķeti

Jaunā POWERTEX sijas satvērēja nomaiņa uz Blackline:

Ja produkts tiks lietots tumšā vietā, pievienojet produkta nosaukuma plāksnei pelēko etiķeti, kā redzams attēlā.

Uz nosaukuma plāksnes norādītajiem datiem VIENMĒR jābūt redzamiem, un to NEDRĪKST aizsegt.

Ja šim izstrādājumam tiek veiktas jebkādas izmaiņas vai tas tiek lietots kopā ar nesaderīgiem izstrādājumiem/detaļām, SCM Citra OY neuzņemas atbildību par sekām saistībā ar izstrādājuma drošību.

Atbilstības deklarācija

SCM Citra OY

Asessorinkatu 3-7

20780 Kaarina

Somija

www.powertex-products.com

ar šo deklarē, ka iepriekš aprakstītais POWERTEX izstrādājums atbilst EK Mašīnu direktīvai 2006/42/EK un EN 13155.

CertMax+

The CertMax+ system is a unique leading edge certification management system which is ideal for managing a single asset or large equipment portfolio across multiple sites. Designed by the Lifting Solutions Group, to deliver optimum asset integrity, quality assurance and traceability, the system also improves safety and risk management levels.



Marking

The POWERTEX Beam Clamp is equipped with a RFID (Radio-Frequency Identification) tag, which is a small electronic device, that consist of a small chip and an antenna. It provides a unique identifier for the beam clamp.



The POWERTEX Beam Clamp is **CE** and UKCA marked.


Standard: EN 13155

User Manuals

You can always find the valid and updated User Manuals on the web. The manual is updated continuously and valid only in the latest version.

NB! The English version is the Original instruction.

The manual is available as a download under the following link:
www.powertex-products.com/manuals



Product compliance and conformity

SCM Citra OY

Asessorinkatu 3-7

20780 Kaarina

Finland

www.powertex-products.com





www.powertex-products.com